

FRAMEGUARD

📖 | FITTING GUIDE



01	CLEAN YOUR FRAME	02	OPEN THE BOX
	Thoroughly clean your frame with bike detergent and an alcohol wipe / spray, then allow to dry completely before fitting the Frameguard.		You will find the moulded Frameguard with 4 self adhesive fastening tabs already mounted. Do not take off the backer from the tabs just yet.
03	BEND THE FRAMEGUARD	04	PEEL OFF BACKERS
	Inside the polymer Frameguard is a metal reinforcing insert. This helps you bend the Frameguard to fit the shape of your frame. Do this with your tabs still in place.		Bring the Frameguard to the frame and press lightly so that the tabs make a light tack to the frame. Undo the Velcro straps and pull the Frameguard away, leaving the tabs fastened to the frame.
05	FIX THE TABS TO THE FRAME	06	ATTACH THE FRAMEGUARD
	Press the tabs firmly all over so that they bend to the shape of your frame (some eBike frames will be almost flat and some conventional alloy tubes will be quite curved), so that the adhesive makes a proper bond.		Thread the Velcro straps through the guide holes and secure the strap. To remove the Frameguard, simply undo the straps and pull it off, leaving the tabs fastened to the frame*.

TEXT ISSUED: 19/02/21 | ISO9001 DOC URO135

Frameguard has been specially designed to fit a wide range of bikes currently available on the market.

You can check to see if your bike has been tested, or submit your own fitting results, by visiting rockstopmtb.co.uk/fitchecker. To help us keep Fitchecker up to date, please tell us your experience, as this greatly supports our riding community.

Additional Velcro Strap Supplied

We've included a spare length of Velcro to assist

in fitting in-case you are unable to attach one of the tabs. Simply remove the tab and thread the Velcro through the holes and around your frame.

Need Spares?

If you have more than one bike that you'd like to protect, then we offer a spare pack of adhesive tabs - to buy, simply visit: rockstopmtb.co.uk/tabs

**Frameguard will not move under wet, muddy or harsh riding/cleaning conditions - however, the tabs will peel away under hairdryer heat, leaving no damage to paint work.*